


FRESNO

Framed By Pass Shower Enclosure Installation Instructions


76" OA Height Fits Standard Opening Range of 54"- 60"

Customization Options Available





HARDWARE INCLUDED


























TOOLS NEEDED







A.1Level side rail and mark holes




A.2 Drill holes




B.1Mount panel guide accordingly using the included blockers that fit your glass thickness












A.1 Position and mark bracket to mount top track




A.2 Drill holes




A.3 Mount brackets with included hardware



B.1 Position top track onto brackets




B.2Use included hardware to mount top track to brackets







A.1




B.1 Position and mark to mount panel guide





B.2Drill holes
through the sill
plate only, not
into the shower
curb.



B.3
Use included hardware to mount panel guide
Use the included blockers that fit your glass thickness and placement in floor guide








A.1

Select the number of gaskets according to the glass thickness











A.2

Insert rollers on to rails as pictured before attaching to glass doors.



B.1

Mount glass doors to hangers and tighten bolts





B.2



C.1


Glass panel should glide smoothly through bottom panel guide and should have a minimum of 1/4" clearance above the sill







C.2

Same steps for installing the second door




C.3Make sure both doors slide gently through panel guide





A.1 Mount towel bars



B.1
Caulk the shower framing and sill Inside and Out where they meet the substrates with 100% silicone. Allow to dry 24 hours before the shower is used

